


E&P Hydraulics WiFi Module



Installation

1. Disconnect the cable from the 'touchscreen' or 'panel'
2. Connect this cable with the 'M' connector on the WiFi module
3. Connect the new cable with the 'P/TS' connector on the WiFi module and the 'touchscreen' or 'panel'

Downloading the app to your mobile phone

To download the app to your phone scan the QR-Code or search for 'E&P Hydraulics' in the store
(Read the manual of your phone for downloading apps)

android



ios



Activating the WiFi Module

There are 3 ways to activate the WiFi module every method below results in activating the WiFi module, choose 1 of the 3 methods below

- Press the 'power/reset' button on the WiFi module
- Press the 'power' button on the 'panel'
- Press the 'automatic' or 'manual' button on the 'touchscreen'

Connecting with the WiFi module

(Read the manual of your phone for WiFi connections)

1. Open the WiFi connection settings on your ios/android device
2. Select the WiFi network "E&P Hydraulics"
3. Enter the password and connect (default password = '00000000')
4. Open the 'EPH level system' app on your phone

Changing the WiFi password

1. Connect with the WiFi module
2. In the 'EPH level system' app open the settings
3. Enter the new password in the WiFi settings and click 'Save'
4. The WiFi module will now restart and you have to follow the steps 'Connecting with the WiFi module' again but this time use the new password

Resetting the WiFi password

1. Press and hold the 'Power/Reset' button for at least 5 seconds
2. The WiFi module will now restart and you have to follow the steps 'Connecting with the WiFi module' again but this time use the default password

Changing the app language

1. Connect with the WiFi module
2. In the 'EPH level system' app open the settings
3. Change the language in the language settings

Changing the system configuration (selecting caravan or motorhome)

1. Connect with the WiFi module
2. In the 'EPH level system' app open the settings
3. Change the system configuration in the system configuration settings

Calibrating the system

1. Connect with the WiFi module
2. In the 'EPH level system' app open the settings
3. Press the calibration button in the calibration settings